

Einstellprogramm für LCD-Uhr

Setting programme for the LCD clock

Programme de réglage pour l'horloge LCD

Programma di regolazione dell'orologio LCD

Instelprogramma voor de LCD-klok

FUNCT. Function selection (time/date) Entry of data

SELECT. Selecting the position, which has to be set

Press the button as long (indication advances in 1/2 second rhythm), or as often, until the desired indication is reached.

X Press once

Indication blinks in 1/2 second rhythm

- By actuating the "SELECT." button after the minutes have been set it is possible to start the clock exactly to the second (e. g. by means of radio or TV time check).
- If the indication "time" is desired at once, then the "FUNCT." button must be pressed 4 times.
  The appearing symbols have no function in this unit.

Attention: After adjustment has been completed, the "SELECT." button must be pressed repeatedly until no sign is blinking.

Setting the clock tin

Setting the clock time					
FUNCT. S 1	SELECT. S 2	Indication	Explanation		
		10:25:8	Initial state: arbitrary time indication		
	(X)	10:25 10	Ready for setting the hours		
		22:2535	Setting hours, clock function not interrupted		
	(X)	22:2540	Ready for setting the minutes, clock function not interrupted		
		22:06:00	Setting minutes, clock function interrupted, seconds at zero		
	(X)	22:0600	Setting process concluded, clock function started, indication, "time" 1)		

Setting the date (week-day, calendar day, month) (German week-day letters)

		22:0630	Initial state: "time"
(X)		MO 8 2	Indication: date
	X	MQ 8 2	Ready for setting the week-day
		00 8 2	Setting week-day
	X	10 B 2	Ready for setting the calendar day
		10 (2 a	Setting calendar day
-	X	DO 12 a	Ready for setting the month
		DO 12 ()	Setting month
	X	00 1211	Setting concluded, indication "date". Changes after approx. 30 secs. back to indication "time". 2)

GB